













Reset

TEXAS
INSTRUMENTS

LAUNCHXL-CC2640R2 Rev: 1.0

WCS030A

XDS110 Out

VSENSE

XDS110
PowerExtern
PwrBTN-1
DIO13

GND

5V

3V3

RXD<<

TXD>>

RESET

TMS

TCK

TDI

TDO

SWO

BTN-2
DIO14

CC2650 In

J1 1 21 J3

3V3

5V

GND

DIO23

DIO3

DIO2

DIO22

DIO24

DIO10

DIO21

DIO4

DIO5

10 30

DIO25

DIO26

DIO27

DIO28

DIO29

DIO30

DIO0

DIO1

LEDs

GND

GND

5V

Red:
DIO6Green:
DIO7

BP Lp DIO7

DIO6

DIO20

DIO19

DIO18

BPRST

TMS

TCK

DIO16

DIO17

31 11

J4 40 20 J2

GND

DIO12

DIO11

LPRST

DIO9

DIO8

DIO13

DIO14

DIO15

GND

GND

3V3

Mount for:
CC-ANTENNA-DK





